

**EDM-K THREE-PHASE METER**



The **EDMk** three-phase electronic energy meter is capable of measuring consumed and generated energy (four quadrants): Active energy (consumed and generated), inductive reactive energy (consumed and generated) and capacitive reactive energy (consumed and generated), plus metering partial energies. Measurements are in true effective value, via three AC. voltage and neutral inputs and three AC. current inputs. (via .../5A or .../1A current transformers). The parameters measured and calculated are shown in the variables table.

This manual is a quick guide to the use and operation of the **EDM-k** energy meter. This manual may be found in electronic format on the **CIRCUTOR** website: [www.circutor.es](http://www.circutor.es)

**!** Before any maintenance, modification to the connections, repair, etc., the equipment must be disconnected from the supply. If any operation or protection fault is suspected the equipment must remain out of service ensuring against any accidental reconnection. The equipment is designed to be changed quickly in the event of any breakdown.

**1.- KEYBOARD FUNCTIONS.**

The **↔** button allows the user to move through the different energy groups (if any): tariff one and partial tariff, or tariff one, two, three and partial tariff (**EDM3k** type). It is used in the set up menu it is used to enter the data and move on to the next parameterisation screen.

The **▲** button the different active or reactive energy display options to be displayed. It is used in the set up menu to increase the value by one digit if a variable has been entered or selected.

Generated or consumed energy can be selected by using **▶** in the option. Inductive or capacitive energy can be selected in the reactive option. In the set up menu, it is used to move the cursor among the digits.

The **Display** button allows the display to come on in the absence of any power supply. This function allows the on site reading of meters when the device is out of service. This option is available when the meter has an *optional* station installed inside (see price list M3).

The **Setup** button gives rapid access to the device's full parameterisation menu. To access this menu, press the button for less than one second.

The **Clear** button deletes partial energies. To do this, press the button for less than 4 seconds. The message will then display **"DONE"**, indicating that these meters have been successfully started (active and reactive).

The **Set A** button starts the meter in one step only with the minimum setting for the meter. (see section *Parameterisation in one step only*).

**2.- STARTING-UP IN ONE STEP ONLY**

**2.1.- Prior information**

This option is only valid for installations where there is no voltage transformer to measure. Voltage is only measured directly (300V AC-<sub>f-n</sub> / 500V AC-<sub>f-t</sub>); and current measurement is via secondary external current transformers of one or five amperes.

**2.2.- Parameterisation in one step only**

Keeping the **Set A** button pressed for 1 second, the energy meter enables the current primary and secondary parameterisation on screen.

Using the **▲** and **▶** buttons the value of the current transformer primary and secondary is validated using the **↔** button.

**3.- COMPLETE PARAMETERISATION OF THE METER**

Using the complete parameterisation of the meter, all setting options can be set. These options affect the setting of the external voltage transformers, if any, as well as the omission of energy meters which the customer believes to be of little relevance or are not required in their installation.

**3.1.- Voltage transformer primary**

On screen the words **"PRI1"** appear followed by 7 digits. These allow the voltage transformer primary to be set (from 1 to 999,999).

**3.2.- Voltage transformer secondary**

On screen the words **"SEC1"** appear followed by 3 digits. These allow the voltage transformer secondary to be set (from 1 to 999).

**3.3.- Current transformer primary**

On screen the words **"PRI2"** appear followed by 5 digits. These allow the current transformer primary to be set (from 1 to 9,999).

**3.4.- Current transformer secondary**

On screen the words **"SEC2"** appear followed by the number 5 or 1. These allow the installed current transformer secondary ratio to be set (5= .../ 5A or 1= .../ 1A).

**3.5.- Measurement in 2 or 4 quadrants**

On screen the words **"QUAD"** appear; one of the two available options must be selected: 2=power consumption or 4=consumption and generation.

**3.6.- Setting the "backlight" disconnection time**

On screen the words **"DISP OFF"** appear; the time the backlight is on can be set after pressing the keypad. The backlight is permanently on if 00 is set.

**3.7.- Display or reactive energy omission**

On screen the words **"REACT"** appear; this option allows the reactive energy to be displayed or omitted ("YES" or "NO").

**3.8.- Partial energy display or omission**

On screen the words **"PART"** appear; this option allows the partial active and reactive energy to be displayed or omitted ("YES" or "NO"). In the event of omission, the meter does not show energy and stops metering energy.

**3.9.- Setting the energy output pulse**

The screen shows **"OUT ACT"**; the energy to be associated to digital output 1 must be selected: Consumed active energy (**IMPORT**) or generated (**EXPORT**); once the data has been entered with the **↔** button, the **W-h** value must be entered by pressing.

The screen shows **"OUT REA"**; the reactive energy to be associated to digital output 2 must be selected: **L / C /**

**L / C**; once the data has been entered with the **↔** button, the **var-h** value must be entered by pressing the keypad. In case of selecting 2 quadrants (see section 3.5.- *Measurement in 2 or 4 quadrants*), only are available **L** and **C**.

**4.- DEFAULT SETTINGS**

The EDMk-ITF-C2 electronic three-phase meter is supplied with the following default settings:

VARIABLE	POINT	VALUE
Voltage primary	3.1	000001
Voltage secondary	3.2	001
Current primary	3.3	0005
Current secondary	3.4	5
Measurement in 2 or 4 quadrants	3.5	2
Backlight disconnection	3.6	10
Reactive energy display	3.7	NO
Partial energy display	3.8	NO
Energy pulses		
- Active energy	3.9	IMPORT
- W-h / pulse	3.9	1000
- Reactive energy	3.9	L
- var-h / pulse	3.9	1000

**5.- TARIFFS (EDM3K TYPE)**

The tariff time is carried out using hardware. The equipment has a common and two inputs free of voltage to select the type of tariff required (Tariff 1, Tariff 2 or Tariff 3).

- Tariff 1: Without any bridge between terminals
- Tariff 2: Bridge between terminal A and S
- Tariff 3: Bridge between terminal B and S

**6.- COMMUNICATION (RS485-C2 TYPE)**

**6.1.- Programming of setting parameters**

Configurable parameters in the parameterisation menu:

- **"NPER"**: Peripheral number 001 to 255
- **"BAUD"**: Baud rate 1200-2400-4800-9600-19200
- **"BITS"**: Length 8 bits
- **"PARI"**: No, Even, Odd
- **"STOP"**: Stop bits 1 or 2

Default settings **001 / 9600 / 8 / N / 1**

**6.2.- Communication protocol**

The **EDMk** meter uses MODBUS RTU@ communication protocol and network protocol RS485. The format is as follows:

QUESTION: NP FT AAAA NNNN CRC

- NP: 1 Byte Peripheral number
- FT: 1 Byte Function 04 reading of n Words
- AAAA: 2 Bytes Address of 1st recording
- NNNN: 2 Bytes Number of recordings to be requested
- CRC: 1 Byte Cyclic Redundancy Checking

In the MODBUS@ recordings, the energy is accumulated in **kW-h x 100** (2 decimal points) with a length of 2 Words.

**6.3.- MODBUS RTU@ memory map**

PARAMETER	REG.
Active energy +	00-01
Active energy -	02-03
Inductive reactive energy +	04-05
Capacitive reactive energy +	06-07
Inductive reactive energy -	08-09
Capacitive reactive energy -	0A-0B
Partial active energy +	30-31
Partial active energy -	32-33
Partial inductive reactive energy +	34-35
Partial capacitive reactive energy +	36-37
Partial inductive reactive energy -	38-39
Partial capacitive reactive energy -	3A-3B

**6.4.- Description communications**

One or more **EDM-k** meters can be connected to a computer or PLC. As well as the usual operation of each piece of equipment, this system may centralize data at one single point.

The **EDM-k** has an RS-485 series communications output. If more than one analyzer is connected to one RS-485 communication bus, it is necessary to assign to each a peripheral address (from 01 to 255) so that the remote computer or PLC sends data on different measured or calculated recordings to those addresses.

The RS-485 connection is made with woven mesh shielded communications cables, with a minimum of three wires and with a maximum distance between remote computer and the last analyzer of 1,200 metres. This RS485 series bus can connect up to a maximum of 32 devices.

The **EDM-k** meter communicates using the **MODBUS RTU** protocol (Pulling Question / Answer).

**7.- DISPLAY**

The **EDMk** energy meter display is divided into two sections: the first of these (on the upper section) displays the value of the energy meters (Active energy and Inductive reactive energy or Capacitive). The second shows the measurement, in real time, being taken by the meter at that time.



STATUS - REAL TIME


- **L1-L2-L3** shows that the device has measured voltage in each phase. If one of these does not exist, the corresponding identification number does not appear. The symbols appearing behind each phase (L) indicate the direction of the current in the current transformers, showing if the point of measurement is consuming or generating energy (*informs of possible errors of connection with the current transformers*).
- **T1 T2 T3** identification only available on the **EDM3k**; shows the tariff selected for that time, independently from the tariff displayed on the upper section.
- The **L** symbol indicates that the load is inductive; the **C** symbol indicates that the load is capacitive.
- The **→** symbol shows that the meter is the first and fourth quadrant (consumption); the **←** symbol indicates that the meter is in the second and third quadrant (generation).

**6.5.- Connection with system converters**

Description of connection for the RS485 bus, for communication via an Intelligent Converter (485-RS232), or via an Ethernet Converter (Transparent / Modbus/TCP).

EDMk-ITF-RS485-C2 M31751	Intelligent Converter M54020	Ethernet Converter M54031 / M54032
RS485 TERMINAL	RS485 TERMINAL	RS485/RS232 TERMINAL
A (+)	1 / A	A
B (-)	2 / B	B
S (GND)	5 / GND	S

**8.- CONNECTIONS**



**9.- TECHNICAL FEATURES**

<b>Power Supply:</b> - Single-phase: - Voltage tolerance: - Frequency: - Maximum burden: - Operating temperature: - Humidity (without condensation):	<b>AC. type</b> 230 V AC. -15 % / +10 % 45...65 Hz 5 VA -20°C .....+ 60°C 5% ..... 95%	<b>AC. and DC. type</b> 85...265V AC. / 95...300V DC. 0...65 Hz 5 VA -20°C .....+ 60 °C 5% ..... 95%	<b>Measurement circuit:</b> - Rated voltage: - Frequency: - Rated current: - Permanent overload: - Voltage circuit burden per phase: - Current circuit burden per phase:	300V AC. <sub>f1</sub> / 500V AC. <sub>f2</sub> 45...65 Hz .../ 5A or .../ 1A 1.2 In 0.3 VA 0.3 VA at 5A and 0.06 at 1A
<b>Mechanical features:</b> - Casing material: - Assembled equipment protection (front): - Non assembled equipment protection (sides and rear): - Dimensions (mm): - Weight:	Self extinguishing V0 plastic IP 51 IP 31 85 x 52 x 70 mm (3 step) 0.210 kg		<b>Pulse output transistors features:</b> - Type: Opto-insulated transistor (open collector): - Maximum operating voltage: - Maximum operating current: - Maximum frequency: - Impulse length:	NPN 24 V DC. 50 mA 5 pulses / second 50 ms
- Accuracy class in Active energy: - Accuracy class in reactive energy:	Class 1 (IEC 61268) Class 2 (IEC 61268)		Standards: EN62052-11, EN62053-21, EN62053-23, EN61010-1 Safety: Category III / EN-61010-1 Class II double insulation against electric shock.	

**10.- TECHNICAL SERVICE**

In the event of any equipment failure or any operational queries please contact the technical service of CIRCUTOR, SA.

CIRCUTOR SA – AFTER SALES SERVICE  
 Vial Sant Jordi, s/n  
 08232 - Viladecavalls (Barcelona)  
 Telephone no.: +34.902.449.459, Other countries + 34 937 452 900  
 Website: [www.circutor.es](http://www.circutor.es)  
 e-mail: [central@circutor.es](mailto:central@circutor.es)